

Boulder 1008 Phono Preamplifier

Owners Manual

V1.0 10/20/2009

Boulder Amplifiers, Inc. 3235 Prairie Ave. Boulder, CO 80301 www.boulderamp.com

APPENDIX

RECORDING

EQUALIZATION

OPERATION

CARTRIDGE SET UP



TABLE OF CONTENTS

<u>GETTING STARTED</u>	
Placement of the 1008 Phono Preamplifier	1-1
Connecting to the Mains Outlet	
Connecting to a Turntable	
Phono Cables Diagram	
Connecting to a Balanced Input Preamplifier	
Connecting to an Unbalanced Input Preamplifier	1-6
<u>CARTRIDGE SETUP</u>	
Personality Card	2-1
Moving Coil or Moving Magnet	
Cartridge Loading – Resistive	
Cartridge Loading – Capacitive	
<u>OPERATION</u>	
Powering Up	
Input Selection	3-2
Mono	
Equalization	3-3
Low Cut Filter	
Mute	3-5

APPENDIX

RECORDING

EQUALIZATION

OPERATION

CARTRIDGE SET UP

<u>EQUALIZATION</u>	
Equalization Curves	4-1
RIAA Reproduce Curve	4-2
FFRR Reproduce Curve	 4- 3
EMI Reproduce Curve	4-4
Columbia Reproduce Curve	4-5
<u>USING A RECORDER</u>	
Connections	5-1
<u>APPENDIX</u>	
Block Diagram	6-1
Specifications	6-2
Troubleshooting	6-3
Notes	

APPENDIX

RECORDING

EQUALIZATION

OPERATION

CARTRIDGE SET UP

GETTING STARTED

PLACEMENT OF THE 1008 PHONO PREAMPLIFIER

Your Boulder 1008 Preamplifier is designed to reduce interference from external magnetic and radio fields (RF). While placement is not critical, known magnetic fields should be avoided. Power transformers in other pieces of nearby equipment should be kept away by 1 foot or more.

Because the preamplifier is heavy, a solid, stable surface should be used. The 1008 will generate some heat, so it should be allowed to have good air circulation.


You may want to have some access to the rear panels for cable changes.



CONNECTING TO THE MAINS OUTLET

Your 1008 Phono Preamplifier is supplied with a mains cord suitable to the location where it was purchased. Make certain that the "O" is pushed on the rocker switch before connecting to your mains.

Your 1008 has been configured for the voltage suited to your location. Exact voltage and frequency specifications are located on the rear panel, right of the AC mains connector.



LEFT

INPUT #1

CHASSIS

GROUND

TERMINALS

CONNECTING TO A TURNTABLE

Balanced inputs are provided for connecting up to two turntables to the 1008. To avoid hum pickup in the cabling, it is important to follow these instructions.

Do not connect pin 1 (chassis/ground) to either pin 2 or 3 at any point in the cable, turntable chassis, or tonearm. Pins 2 and 3 must only connect directly to the cartridge pins. This can be accomplished by several wiring schemes shown on the next page.

Do <u>not</u> use the Boulder ABL2 input adapter or other "standard" RCA Phono to XLR adapter because they connect pin


1 to pin 3. These are intended only for line level use.

Use <u>either</u> a connection from pin 1 to the turntable chassis or a wire from the CHASSIS screw terminal to the turntable chassis. Using both might form a ground loop which will create hum.


One pair of Boulder PHRCA Adapters are provided. These will convert 1008 inputs to RCA and give acceptable performance. A separate ground wire is provided. However, obtaining a dedicated cable with a connector specifically for your tonearm and with 3-pin connectors is preferred.

RIGHT

INPUT #1



1-4



CONNECTING TO A BALANCED INPUT PREAMPLIFIER


For maximum sonic advantage, connect your 1008 Preamplifier's balanced outputs to balanced inputs such as provided on all Boulder Preamplifiers. With the 1008's low output impedance, distances of more than 50 meters between Phono Preamplifier and Line Preamplifier are practical. Connect each preamplifiers input to the connectors labeled "OUTPUT."



CONNECTING TO AN UNBALANCED INPUT PREAMPLIFIER

A special cable is required to make this connection. This cable connects pin 1 to the shield and pin 2 to the center pin. It leaves the output pin 3 unconnected.

Connecting the unused output pin (usually pin 3) to ground will cause excessive ground currents and degrade performance. Use an ohmmeter or continuity checker to determine how a cable is wired.









CARTRIDGE SET UP

PERSONALITY CARD

Each 1008 input has two slots for personality cards, one for left, and one for right channels. The cards serve two functions—a switch to set the electronics for the type of cartridge used at that input, and places to solder the custom load termination resistor and capacitor.


The 1008 is shipped with all 4 cards installed in the rear panel.

The cards are set to MC, and have a load resistor installed to set the input impedance to 100Ω . These are the most commonly used settings for a MC cartridge.

WARNING: Press the STANDBY pushbutton until the STANDBY indicator is off before removing or inserting the personality card. Failure to do so might result in very loud clicks.

To remove, pull the card firmly. To insert, push the card until it completely seats into the connector and the face is flush to the panel.

CARTRIDGE SET UP




MOVING COIL OR MOVING MAGNET SELECTION

Set the switch to either Moving Coil (MC) or Moving Magnet (MM) depending on your type of cartridge.

In the MC position, the maximum input resistance is $1{,}000\Omega$ without additional components installed on the card. All four of the cards are shipped with a resistor to bring the impedance down to 100Ω , which is recommended for MC. Also in the MC position, an additional low noise, 26 dB gain stage is inserted at the input.

In the MM position, the maximum input resistance is 47K Ω without additional components installed on the card. This is the impedance recommended for MM.





CARTRIDGE LOADING - RESISTIVE

For MC cartridges, the maximum resistive load is $1,000\Omega$. This is the value when there is no resistor added to the Personality Card. This value may be lowered by adding a resistor (as shown) at R1 whose value is calculated by the following:

$$R1 = 1/(1/R_{DESIRED} - .001)$$

Some typical values are:

Desired R (Ω)	$R1(\Omega)$
50	52.3
100	110
200	249
500	1,000

For MM cartridges, the maximum resistive load is $47k\Omega$. This is the value when there is no resistor added to the Personality Card. This value may be lowered by adding a resistor (as shown) at R1 whose value is calculated by the following:


$$R1 = 1/(1/R_{DESIRED} - .0000213)$$

Some typical values are:

Desired R (Ω)	<u>R1 (Ω)</u>
1,000	1,020
5,000	5,620
10,000	12,700
20,000	34,800

CARTRIDGE SET UP





CARTRIDGE LOADING - CAPACITIVE

The 1008 Phono Preamplifier inputs have only "parasitic" capacitance of less than 50 pF directly across the cartridge inputs. If desired, additional capacitance can be added on the personality card at C1. The capacitor chosen should be 50 pF less than the desired value.

Solder holes are provided for two different size capacitors. There are two pairs of holes as shown, two at left and two at right. Each pair is connected together. The capacitor need be soldered to only one of the left and one of the right holes.

All solder holes have grommets to reinforce the PC board when parts are installed and removed. Do not remove these grommets.

BOULDER SUGGESTS: While there are some cartridge manufacturers who recommend using capacitive loading, we suggest that you do not. Adding more capacitance only lowers the resonant frequency of the capacitor and the cartridge winding inductance, particularly with MM cartridges. The resonance peak is still just as high and destructive to the sound.

Instead, try a lower resistor value; the lower the value, the "heavier" the load and the lower the resonance peak (not frequency) thus giving better dampening to the cartridge.

With low level MC cartridges, there is virtually no effect of capacitive loading because the cartridge output impedance is inherently very low







OPERATION POWERING UP

With all your connections made, you are ready to listen to your Boulder 1008 Phono Preamplifier.


Push on the "I" of the rocker switch on the rear panel of the 1008. No indication on the front panel will be shown.

Press the STANDBY pushbutton on the front of the 1008. The STANDBY indicator will be amber. The MUTE indicator will be red and the output will be muted for the first 35 seconds to allow for circuit warm up.

The front panel STANDBY pushbutton can be used for everyday turn on and off. This pushbutton mutes the outputs, turns off the audio electronics, and puts the 1008 in standby mode.

If you are going to turn off the 1008 rear main power, it is highly recommended to turn off the 1008 by first pressing the front panel STANDBY pushbutton.







INPUT SELECTION

The Boulder 1008 Phono Preamplifier provides inputs for 2 cartridges. These can be from one or more turntables. Only one of these inputs can be used at a time.

Select an input by pressing one of the pushbuttons labeled "INPUT 1" and "INPUT 2". The 1008 will immediately mute the outputs and the MUTE indicator will be red for 3 seconds. After that time, the output will be unmuted and the MUTE indicator will be off.

Anytime a different input is selected, the 1008 will similarly mute for 3 seconds.

It is not recommended to select an input that has no cartridge connected. Make connections to an input first and then select the input. If it is necessary to have all inputs disconnected, then mute the preamplifier temporarily.

MONO


To enhance monaural recordings played with a stereo cartridge, it is often desired to mix the left and right channels together to form a true monaural signal. In the 1008 it is possible to do this by turning on MONO mode.

Pressing the MONO pushbutton will place the 1008 into monaural mode and the MONO indicator will be red.

To return to normal stereo operation, again press the MONO pushbutton. The MONO indicator will be off.

OPERATION





EQUALIZATION

The Boulder 1008 Phono Preamplifier provides the standard RIAA record equalization curve, along with the EMI, Columbia, and FFRR curves. See the Equalization section for more details.

Select the RIAA equalization curve by pressing the pushbutton labeled RIAA. All three remaining curves may be selected by using the pushbutton labeled ALT EQ. Various alternate EQs are selected by repeatedly pushing "ALT EQ" until the desired LED is red. The 1008 will immediately mute the outputs and the MUTE light will be red for 3 seconds. After that time, the output will be unmuted and the MUTE indicator will be off.

Anytime a different equalization is selected, the 1008 will similarly mute for 3 seconds.

If the chosen equalization curve is RIAA, the RIAA indicator will be amber. If the chosen equalization curve is any other EQ curve, its respective indicator will be red.



LOW CUT FILTER

The Boulder 1008 Phono Preamplifier uses a 3 pole (18 dB/octave) low cut filter which is -3db at 10 Hz.

Because this filter is fairly steep, its effect is virtually negligible in the audio band. It is recommended that it be kept turned on in order to avoid excessive woofer travel caused by imperfect records.

Select the low cut filter by pressing the pushbutton labeled LOW CUT. The indicator will then be amber.

To completely turn off the filter, again press the pushbutton labeled LOW CUT. The low cut filter will be switched out and the indicator will turn off.

WARNING: Due to some low frequency content of many recordings, care should be taken in regard to volume level when turning the low cut filter on or off as there may be some audible transient (click). This effect is normal.





MUTE

The Boulder 1008 Phono Preamplifier provides an output mute feature which is turned on by two different methods.

First, the outputs are muted for 35 seconds when the 1008 is first turned on. The 1008 is also muted for 3 seconds when an input or equalization pushbutton is pressed. The MUTE indicator will be red.

Second, the outputs may be muted at any time for your convenience by simply pressing the MUTE pushbutton. the MUTE indicator will be red.

To unmute, press the MUTE pushbutton again. The MUTE indicator will turn off and the outputs will unmute unless there has been a cycle initiated by the first method above. In that case the outputs will remain muted and the MUTE indicator red until that timeout has finished.

When the STANDBY pushbutton is used to turn off the 1008 or there is no power, the outputs will be muted.







EQUALIZATION

EQUALIZATION CURVES

The Boulder 1008 Phono Preamplifier uses one of four equalization curves selected by the front panel pushbuttons labeled RIAA and ALT EQ. The 1008 is shipped with four standard EQ options: RIAA, FFRR, EMI, and Colombia.


The following pages show the four equalization curves. All graphs are referenced to 0 dB at 1 kHz.





RIAA REPRODUCE EQUALIZATION


REF 0 DB AT 1 KHZ





FFRR REPRODUCE EQUALIZATION


REF 0 DB AT 1 KHZ






EMI REPRODUCE EQUALIZATION

REF 0 DB AT 1 KHZ





COLUMBIA REPRODUCE EQUALIZATION



4-5

-25.00


20



2K

20K

200 Frequency in hz




USING A RECORDER CONNECTIONS

A recording device may be connected to the Boulder 1008 Phono Preamplifier. You may use balanced or unbalanced connections for both input and outputs as previously described in the sections on connecting sources and power amplifiers.

Either of the outputs may be connected to the input of your recording device.





BOULDER 1008 PHONO PREAMPLIFIER SPECIFICATIONS

Inputs

Input Impedance, Maximum

1kHz Gain, RIAA Noise (EIN), MC

Outputs

Maximum Output Level

Distortion, THD

Frequency Response, 20 Hz to 20 kHz

Crosstalk, L to R or R to L

Output Impedance

Preamp Size, W X H X D

Weight

Power

2 Balanced, Converts to Unbalanced

MC: 1000 Ω ; MM: 47k Ω

MC: 70, MM: 44

98 nanovolts Flat, 20 Hz to 20kHz 2 Balanced, use as Main or Record

16 Vrms 0.01%

RIAA: ±0.10 dB

>100 dB or better 20 Hz to 20kHz

100Ω Balanced

18.0 x 5.0 x 15.85 inches 32, Shipping: 41 pounds

50-60 Hz, 30W, Voltage by country

TROUBLESHOOTING			
SYMPTOM	CAUSE	REMEDY	
No power indication on 1008	Power switch is not in ON position	Turn on power switch	
	1008 is not plugged in	Connect to an AC outlet	
	Home circuit breaker is tripped	Reset circuit breaker	
	Low AC line voltage	Have AC line checked	
	Power supply fuse blown	Replace fuse on rear panel	
	Defective 1008	Return to dealer for service	
Amber power indication on 1008, but no sound is heard	1008 is muted, MUTE indication is Amber	Press MUTE pushbutton to turn mute indicator OFF	
	No signal from turntable	Check turntable connections	
	No signal out to preamplifier	Check connections to preamp	
	1008 is faulty	Return to dealer for service	
Hum through loudspeakers	No ground connection	Check or install ground wire	
	Duplicate ground connection	Use only one ground wire to turntable or use the ground in a balanced cable	
	1008 or turntable is too close to another components power supply	Move 1008 and/or turntable away from power supply	

TROUBLESHOOTING		
SYMPTOM	CAUSE	REMEDY
One channel is louder than the other	MM/MC switch is not set the same on both channels	Set MM/MC switches on personality cards to the same setting
	Cartridge loading is not equal	Check cartridge loads on personality cards
Tonality or frequency response is incorrect	Wrong equalization setting is selected	Press ALTERNATE EQ button to select proper EQ setting
Will not come out of Mute	1008 has not been stabilized after turn-on	Wait 35 seconds for 1008 to stabilize

Serial Number _____

6-5